



Auto Care USA
a division of Northwest Equipment Manufacturing, Inc.
122 East Reserve Dr. • Kalispell, MT 59901 USA
• Office: 406-755-0805 • Fax: 406-755-0813
nwEquipmentSales.com



Reach us at: 877-349-2327 or 406-755-0805

NWES 0061 Magnetic Transfer Adapter

NWES 0061 Magnetic Transfer Adapter – Eliminates the need to (1) jack the vehicle, (2) Remove the wheel nut, (3) Place adapter on the wheel, (4) Replace the wheel nut, (5) Lower the vehicle, and then attach the Magnetic Gauge. It fits over the wheel nut directly on the hub, transferring the magnetism of the Magnetic Gauge, holding it securely in place for accurate measurements and adjustments. The adapter is reversible for outside diameters of 2-1/4" and 2-5/8". Especially designed for front-wheel drive cars, the Magnetic Transfer Adapter fits 85% of cars and light trucks.

The wheel hub is the only machined surface on the wheel and therefore gives 100% accuracy to measure caster, camber, and axis inclination. When the hub cannot be reached directly with the magnetic gauge, an adapter is required.

If the configuration of the wheel is such that access to the hub is impossible, the No Mar Rim Adapter should be used.

The adapter is different on each side. It is designed to fit over the various wheel nuts and holes up to 2-1/4" diameter using one side, and 2-5/8" diameter using the other side. It simplifies the access of the magnetic gauge onto the wheel hub.

1. Place the NWES 0061 Magnetic Transfer Adapter on the Magnetic Caster/Camber Gauge, visually centered, exposing the surface of the adapter that fits inside the wheel hole.
2. Place the magnetic gauge with the adapter in place against the wheel hub as if using the magnetic gauge alone.